

**RECOMMENDED SPARE PARTS FOR  
1216 SHAKER**

<b>PARTS #</b>	<b>DESCRIPTION</b>	<b>QUANTITY</b>
716111	Armature Assembly	1 ea
715706-1	Field Coil Assembly	2 ea
715190	Diaphragm Load Support	1 ea
80201-0065	Bearing-Armature Guide	1 ea
83019-0017	Bearing "O" Ring	2 ea
81215-0046	Plug Plastic	1 ea
715716	Flexure Assembly	4 ea
715713	Filter Top Cover	1 ea
715712	Rolling Seal Top Cover	1 ea
715780	Current Lead	1 ea
81223-0170	Switch (Air flow)	1 ea
82110-0136	Diode, 70A 1000	1 ea
715783	4" Load Support Shaft	1 ea