

**RECOMMENDED SPARE PARTS FOR
4522 SHAKER**

| PARTS # | DESCRIPTION | QUANTITY |
|----------------|----------------------------|-----------------|
| 716333 | Armature (without inserts) | 1 ea |
| 714269 | Upper Bearing | 1 ea |
| 714257 | Lower Bearing | 1 ea |
| 716407-1 | Inner Current lead | 1 ea |
| 716407-2 | Middle Current Lead | 1 ea |
| 712725 | Top Field Coil | 1 ea |
| 712726 | Bottom Field Coil | 1 ea |
| 34264 | 340 Flexure Assy. | 4 ea |
| 81217-0031 | Hose, Armature Top Water | 10 ft |
| 714269 | Bearing, upper | 1 ea |
| 714257 | Bearing, Lower | 1 ea |
| 716415 | Seal Diaph. Rolling | 1 ea |
| 82122-0063 | Oil Filter 10 Micron | 1 ea |
| 110324 | Bushing, Connector | 10 ea |
| 22018-4 | Oil Tube Pressure | 1 ea |
| 22213-7 | Oil Tube Return | 1 ea |
| 82110-0138 | Diode | 1 ea |
| 82214- 0005 | Pot Mini Rheo 225W | 1 ea |
| 714804 | Cable OT/DG/OPCS | 1 ea |