

**RECOMMENDED SPARE PARTS FOR
612 SHAKER**

PARTS #	DESCRIPTION	QUANTITY
715149	Armature Assy.	1 ea
705951	Field Coil	2 ea
110043	Flexure Assy.	4 ea
25409	Armature Current Leads	2 ea
111664-3	Air Inlet Filter	1 ea
82110-0134	Diode 40A 600V	1 ea
24605	Insulator (Flex.)	2 ea
82476-0008	Current Lead Insulation Washer	8 ea
82460-0076	Nylon Spacer/Current Lead	4 ea
81223-0170	Switch, Diff. (Air flow)	1 ea
36141	Air Bearing Assy.	1 ea
715180	Shaft, with load support	1 ea.
715178	Shaft (only, without load support)	1 ea.
715238	Rolling diaphragm	1 ea.