

**RECOMMENDED SPARE PARTS FOR  
816 SHAKER**

<b>PARTS #</b>	<b>DESCRIPTION</b>	<b>QUANTITY</b>
718559	Armature Assy.	1 ea
705951	Field Coil	2 ea
715161	Flexure Assy.	4 ea
715158	Armature Current Leads	2 ea
716371	Air Inlet Filter	1 ea
82110-0134	Diode 40A 600V	1 ea
711823	Bearing Assy.	1 ea
715171	Armature Shaft	1 ea
715190	Diaph. Load Support	1 ea
81223-0170	Switch, Diff. (Air flow)	1 ea
715157	Over Travel Switch	1 ea
712436	Armature Lead Insul.	2 ea